

Quick Installation Guide

MultiPlus-II 48V 3000VA 230Vac


www.victronenergy.com

Included





For fuse values:
refer to the user manual


Fuse (not included)



Not included





1




2

Terminals explanation Read the manual


- 1 - Remote On/Off
- 2 - VE.Bus
- 3 - VE.Bus
- 4 - AUX I/O
- 5 - Current Sense
- 6 - Aux Relay




4




5




6




7



8



9



10